

TDS0070 Established: 18 Feb 2015 Updated: 20 Feb 2023

TECHNICAL DATA SHEET FOR

ODOUR-LESS MEDIFRESH

DESCRIPTION : Odour-Less Medifresh is a high-quality interior paint with a classic

matte finish that has been specially formulated to have virtually no odour. In addition, it has an air purifying function that continuously absorbs harmful formaldehyde from the air, improving indoor air quality. This makes it an ideal choice for use in both commercial and residential

settings.

TYPE : Acrylic polymer emulsion

COLOUR : As per colour card

FINISH : Classic matte

USES : • Internal masonry surfaces, such as cement, plastered walls.

brickwork and fibre boards

Ideal for use on interior walls of hospitals, schools, offices and

residential buildings

FEATURES : • Low emission

Air purifying - formaldehyde abatement property

• Ultra-low odour

Near zero VOC

Non-toxic, does not contain lead, mercury and heavy metals

 Ammonia-free, Alkyl Phenol Ethoxylate (APE) surfactant-free, formaldehyde-free

Mould and fungus resistant

Anti-bacterial property reduce common bacteria (E.Coli, MRSA and
Otanbada analysis August) - #faction!

Staphylococcus Aureus) effectively

Easy application

Excellent flow and levelling

Spatter-resistant

Excellent coverage and hiding power

Excellent stain resistance and washability

Environmentally friendly paint certified under the Singapore Green

Building Product Certification Scheme

APPLICATION DATA

METHOD : Roller or brush

THEORETICAL COVERAGE : $10 - 12 \text{ m}^2 / \text{litre at dry film thickness of } 35 \, \mu$

DILUTION : No dilution is necessary for best performance



TECHNICAL DATA SHEET FOR

ODOUR-LESS MEDIFRESH

SURFACE PREPARATION

Ensure the surface is properly prepared before application. Follow these steps:

- Moisture: The surface must be completely dry and free of any water residue. Moisture must be <4% using a Sovereign moisture master) before application.
- Unstable matter: Remove any loose or unstable material such as peeling paint, rust, mill scale, and dirt by high-pressure water jet wash or mechanical means such as power brush or scraper, whichever is appropriate.
- **Contaminants:** Clean the surface of any dust, dirt, oil, or grease using a damp cloth and, if necessary, a mild detergent or solvent. Allow the surface to dry completely
- Fungus and Algae: Wash the affected area to remove unstable materials and microorganisms, and then apply an anti-fungus solution and leave it on for at least 2 hours
- Hairline cracks: Fill any hairline cracks with a suitable exteriorgrade, water-resistant putty or filler

DRYING TIME : Surface Dry : 30 minutes at 30 °C

Hard Dry : 2 hours at 30 °C

OVERCOATING TIME : 2 hours minimum based on normal conditions

RECOMMENDED PAINTING :

SYSTEM

• 1 coat 5101 Odour-less Sealer

2 coats Odour-Less Medifresh

CLEANING : All equipment should be cleaned with water immediately after use

GENERAL INFORMATION

SOLID CONTENT : $58.0 \pm 2.0 \%$ by weight (based on white colour)

DENSITY : $1.36 \pm 2.0 \%$ kg / litre (based on white colour)

PACKING : 1 litre and 5 litres

STORAGE : Store in a tightly sealed container in a cool, dry place

SHELF LIFE : Up to 24 months in a tightly sealed container

PRECAUTION : Ensure good ventilation during application and drying of paint. Avoid

direct contact with sensitive skin. Use appropriate personal protective

equipment

Refer to the product Safety Data Sheet for more information

TECHNICAL DATA SHEET FOR

ODOUR-LESS MEDIFRESH

The information given is intended to give a description of the product performance under specific test conditions. Nevertheless, we cannot assume any responsibility for the use of it since circumstances under which the products are applied in practice are subjected to many variations. We reserve the right to alter the given data without notice

Enquiries / Contact Details : Customer Service

6265 6265 5355 (Main Line)

6264 1603 (Fax)

www.nipponpaint.com.sg